



Moisture Barrier

UNDERLAYMENT



UL-MB6 Moisture/Vapor Barrier Underlayment

MATERIAL	Polyethylene Film
THICKNESS	6 mil
ROLL WEIGHT	14.5 lbs
SQ. FT. PER ROLL	500 sq. ft.
WARRANTY	Limited Lifetime
DIMENSIONS	125 ft. Length x 4 ft. Wide

Includes overlap and tape for easy installation.

Installation instructions on reverse side.



For best results when installing your floating floor, we recommend Lions Floor Premium Moisture/Vapor Barrier Underlayment. Our underlayment offers exceptional sound dampening properties, acts as a reliable moisture barrier, and effectively impedes the growth of mold and mildew.



Moisture Barrier Underlayment **INSTALLATION GUIDE**

PLEASE READ COMPLETELY BEFORE INSTALLATION

Protection from moisture has never been easier. Use this thin, durable, and affordable vapor barrier! Use the Lions Floor Moisture barrier for floating flooring installations over concrete or any subfloor with potential moisture issues.

Lions Floor Moisture Barrier can be used with laminate and SPC products with pre-attached underlayment pad. Follow these easy instructions to get your vapor barrier installed correctly!

Gather Your Tools:

Good organization will help to start your project smoothly. Gather all your supplies for both the underlayment and flooring installation.

- Lions Floor Moisture Barrier Underlayment
- Waterproof Tape
- Scissors or Utility Knife
- Broom or Shop Vac

Begin the Installation:

Step 1: Properly Prepare your Subfloor

Before you start installing the vapor barrier, properly prepare your subfloor. Following flooring installation requirements for the flooring product you will be installing. Your area should be completely free of dust and debris.

Step 2: Lay the Rows of Underlayment

Roll the moisture barrier out perpendicular to the direction you are installing your floor. You will want to overlap the vapor barrier 4" to 6" and use attached edge tape on product to bond seams. All cross seams and fill pieces that have no edge tape, overlap, and use waterproof tape to bond seams. You can let the moisture barrier run up the wall slightly where it will be covered by the baseboard or quarter round after flooring installation is complete. Continue laying rows until the entire flooring installation area is completely covered and all seams overlapped and taped.